

# 10' x 10' MeshPanel Booth Frame

Canopy Ready for 10 x 10 TrimLine

## Assembly Instructions

### Parts:

- (4) Canopy Corner Joints
- (2) StaBar 3 Way Joints
- (2) StaBar Ell Joints
- (4) Feet



Foot



Canopy Corner Joint

- (5) Male pole sections – 61" long
- (5) Female pole sections – 58 1/4" long
- (2) Male pole sections – 61" long, Coded Purple
- (2) Female pole sections – 58 1/4" long, Coded Purple
- (4) Telescoping Legs, bottom section nested inside top section




StaBar 3 Way




StaBar Ell

- (8) Ball Bungees, for bundling poles
- (18) Thumbscrews


### Assembly:



1. Connect male and female pole sections by clicking together to form (7) poles that are 116 1/2" long. Purple coded and no-color code poles are interchangeable for indoor use.
2. Slide StaBar Joints onto the bottom of the telescoping legs. StaBar Joints should be oriented so that the white arrow points down. Click a foot into place at the bottom of all (4) legs.
3. Lay out the top frame using (4) of the 116 1/2" poles and. Connect poles using Canopy Corner Joints to form the top frame as shown below.



4. Lifting the frame onto it's legs can be done by one person but is much easier with two. Ask a neighbor for a hand (it will only take a minute). Begin at the back corners of the booth.
5. With each person holding a leg that has a **StaBar 3 Way Joint** on it, lift the rear corners of the frame and insert legs into the Corner Joints.
6. Repeat at the front of the booth, using legs with **StaBar Ell Joints**.



7. To complete your MeshPanel Booth Frame, insert remaining poles into StaBar Joints, clicking into place. Begin at the back of the booth, then install the sides.
8. Finger-tighten all thumbscrews. **Do not use tools!**

\*If you will be using a French Wall Frame with your booth, refer to those instructions before beginning set up of the MeshPanel Booth Frame.